


CARL-AVI-01

Miyota caliber 9075 - Instruction manual

IMPORTANT:

To ensure optimum water resistance, the crown of the CARL-AVI-01 is screwed.
Before any time resets or adjustments, remember to unscrew it.
Do not forget to screw it back in after any manipulations, otherwise the watch may no longer be water resistant. This would cause irreparable damage.

1/ DISPLAY AND FUNCTIONS



2/ WINDING THE MAINSPRING

Automatic winding watch can be also manual-winded by turning the crown in "A" position.
Wind 15/20 times clockwise until second hand starts to move naturally.

3/ ADJUSTING DATE AND TIME

Pull the crown in position "C" to set the 24 hour and minute hands to home time.
Return the crown to position "A", then pull the crown in position "B" to set the hour hand and date to local time.

- ▶ When the hour hand turns twice, the date will change by one day.
 - ▶ When setting the time, pay attention to AM or PM.
- ▶ When setting the time anticlockwise between 21:00 and midnight, set it back until the date switches to the previous day.

4/ ADJUSTING LOCAL TIME

This movement allows you to change hour hand without stopping other hands.
Pull the crown at position "B" to change the hour hand by one hour.