
# CARL-MIL-01

## Miyota caliber 9039 - Instruction manual

#### 1/ DISPLAY AND FUNCTIONS



### 2/ WINDING THE MAINSPRING

Automatic winding watch can be also manual-winded by turning the crown in "A" position. Wind 15/20 times clockwise until second hand starts to move naturally.

#### 3/ ADJUSTING TIME

Pull the crown in "B" position and adjust the standard time.

